


Installation Instruction

MOBILIZER - K

for 2001-2004 K&D Series ECU's*



*) Working ECU's are: PLM, PLR, PND, PNF, PRA, PRB, PPA